

Sigrist Exit Seal®

Installation Instructions



Tools Required:

- 2 1/4" diameter metal cutting hole saw or punch
- Small hand file for de-burring the hole

Note: Before you drill, start on the lowest row making it easier to add lines above later

Installation Steps

1. Drill/punch a 2 1/4" diameter hole using Alta Products 'locator-indent'
2. Remove *only* the Backing Nut from the Body before inserting the Body into newly cut hole
3. Hand tighten (*not wrench*) the Backing Nut onto Body from inside the housing
4. The Sigrist Exit Seal® is now ready for the line to be installed

Sigrist Exit Seals® can be damaged if exposed to open flame and/or high temperatures during soldering

IMPORTANT NOTE

Protect the Sigrist Exit Seal® by **sliding the cap, cap gasket and guide washer away from the joint** and *wrap parts with wet cloth*

CAUTION: Sigrist Exit Seals® are not designed to contain or seal pressurized liquids or gases.

*standard feature on all medium and small size pipe chase housing units

