Installation ALTA Aluminum Exit Seal Kits

1. Ring kit consists of 2 aluminum rings, 2 gaskets and six screws with nuts
2. Hole should be 1/8” larger than the OD of the pipe
3. Place aluminum ring on housing and mark screw holes
4. Drill the marked screw holes
5. Place one aluminum ring with one gasket on outside of the housing
6. Attached screws slightly to hold the aluminum ring and gasket in place
7. Place the other aluminum ring and gasket on inside of housing.**
8. Finish tightening screws and secure with the nut.

In the event you have insulation on the pipe. The insulation will butt up to each side of the exit seal

NOTE: The sequence is Aluminum ring, gasket outside of housing, inside of housing, gasket and aluminum ring.

The gaskets will be 1/8” smaller than the pipe to secure a tight fit